


LED TROFFER FIXTURE(New Construction)






- Cloud series led troffer gives >1251m/W
- Cloud series troffer can work with emergency power pack.
- Suitable for Damp Location
- 5 years' warranty.


PARAMETER

				De	escription	Lumens		
Length	Product code	Certification	CRI	Wattage	Function	3000/4000/5000K	Packing/carton	G.W./carton
2x2ft	ZS-TF2*2-Q01-S40-3050	ETL/cETLus,DLC,	>80	20/30/40W	3-in-1 dimming(0-10V;PWM;Rx) CCT Tunable & Power adjustable	2500-5000 LM	640*120*640mm 2 pieces 1*40HQ Loading=2736pcs	7kg
							640*230*640mm 4 pieces 1*40HQ Loading=2880pcs	13kg
2x4ft	ZS-TF2*4-Q01-S60-3050	ETL/cETLus,DLC,	>80	40/50/60W	3-in-1 dimming(0-10V;PWM;Rx) CCT Tunable & Power adjustable	5000-7500 LM	1250*120*640mm 2 pieces 1*40HQ Loading=1368pcs	12.2kg
							1250*230*640mm 4 pieces 1*40HQ Loading=1440pcs	23kg

WIRING DIAGRAM








Ensure the power supply has been cut off before connecting the wire, and all wiring and installation of this product are required to be operated by professionals.

INSTALLATION INSTRUCTION



- Step 1: Make sure of all the power is off before installing. Remove the one ceiling tile that you need to install light fixture on. Then place the light fixture on the T-bar carefully and make sure it is correctly in place and secure.
- Step 2: Lift the 4 buckles on the back of the panel up by 90° then bend the top part of the buckles 90° towards the direction where you can anchor the light fixture to the T-bar.
- Step 3: Open the driver's junction box and connect the AC wire to the driver correctly (L=black & N=white)

Warning:

Ensure the power supply has been cut off before connecting the wire, and all wiring and installation of this product are required to be operated by professionals.